VGN-A63/A73PS/A73S VGN-A790 VGN-A417M/A417S/A497XP VGN-A49CP/A49GP

SERVICE MANUAL

Ver. 6 2005H

Revision History

Area	Model	Lineup	
		VGN-A63	
Japanese	Japanese	VGN-A73PS*	
'		VGN-A73S*	
American	US Canadian	VGN-A790	<u>3</u> [MA]
		VGN-A417M	1 [MA]
European	AEP/UK	VGN-A417S	1 [MA]
		VGN-A497XP	1 [MA]
Asian/Oceania/	International	VGN-A49GP	2 [MA]
South Africa	Chinese	VGN-A49CP	4 [MA]

*: CTO Model













- Design and specifications are subject to change without notice.
- ・本機の仕様および外観は、改良のため予告なく変更することがありますが、ご了承ください。

PERSONAL COMPUTER



Information in this document is subject to change without notice.

Sony, VAIO and CLIE are trademarks or registered trademarks of Sony. Microsoft, Windows, Windows Media, Outlook, Bookshelf and other Microsoft products are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries. The word Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG, Inc. AMD, AMD logo, AMD Duron and combinations there of, 3DNow!, are trademarks of Advanced Micro Devices, Inc. Intel Inside logo, Pentium and Celeron are trademarks or registered trademarks of Intel Corporation. Transmeta, the Transmeta logo, Crusoe Processor. the Crusoe logo and combinations there of are trademarks of Transmeta Corporation in the USA and other countries. Graffiti, HotSync, Palm-Modem, and Palm OS are registered trademarks, and the Hotsvnc logo and Palm are trademarks of Palm, Inc. or its subsidiaries. (M) and Motrola are trademarks of Motrora, Inc. Other Motrola products and services with (R) mark like Dragomball are the trademarks of Motrola, Inc.

All other names of systems, products and services in this manual are trademarks or registered trademarks of their respective owners. In this manual, the (TM) or (R) mark are not specified.

Caution Markings for Lithium/Ion Battery - The following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

CAUTION: The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C (212°F) or incinerate. Dispose of used battery promptly. Keep away from children.

CAUTION: Changing the back up battery.

- Overcharging, short circuiting, reverse charging, multilati on or incineration of the cells must be avoided to prevent one or more of the following occurrences; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.
- If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any protection.

Service and Inspection Precautions

1. Obey precautionary markings and instructions

Labels and stamps on the cabinet, chassis, and components identify are as requiring special precautions. Be sure to observe these precautions, as well as all precautions listed in the operating manual and other associated documents.

2. Use designated parts only

The set's components possess important safety characteristics, such as noncombustibility and the ability to tolerate large voltages. Be sure that replacement parts possess the same safety characteristics as the originals. Also remember that the \triangle mark, which appears in circuit diagrams and parts lists, denotes components that have particularly important safety functions; be extra sure to use only the designated components.

3. Always follow the original design when mounting parts and routing wires

The original layout includes various safety features, such as inclusion of insulating materials (tubes and tape) and the mounting of parts above the printer board. In addition, internal wiring has been routed and clamped so as to keep it away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicate the original layout.

4. Inspect after completing service

After servicing, inspect to make sure that all screws, components, and wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

5. When replacing chip components...

Never reuse components. Also remember that the negative side of tantalum capacitors is easily damaged by heat.

6. When handling flexible print boards...

- The temperature of the soldering-iron tip should be about 270°C.
- Do not apply the tip more than three times to the same pattern.
- Handle patterns with care; never apply force.

Caution: Remember that hard disk drives are easily damaged by vibration. Always handle with care.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFÉS PAR UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPÉMENTS PUBLIÉS PAR SONY.

Confidential

TABLE OF CONTENTS

Section

Title

Section	Title	Page
CHAPTER '	1. SPECIFICATIONS	
1-1. Specificar	tions	1-1
•		(to 1-1)
CHAPTER 2	2. BLOCK DIAGRAM	
2-1. VGN-A S	Series	2-1
2-2. Port Repl	licator (VGP-PRAV)	2-2
		(to 2-2)
CHAPTER 3	3. FRAME HARNESS DIAGRAM	
3-1. VGN-A S	Series	3-1
3-2. Port Repl	licator (VGP-PRAV)	3-2
		(to 3-2)
	4. EXPLODED VIEWS AND PARTS LIST	
Palmrest		
	nrest	4-2
Main Board		
	in Board	4-4
Bottom		1.6
	om	4-6
Optical Drive	1.10	4.0
•	ical Drive	4-8
LCD	217 1 WING ((4.10
	17-inch WUXGA (Clear Black LCD) – Made by SH –	
	17-inch WXGA+ (Clear Black LCD) – Made by AU –	4-12
Accessories		4.14
	essories	
	essories	
DIP Swite	ch	
		(to 4-17)

CHAPTER 5. OTHERS	
5-1. The Barcode Label	5-1
5-2. Replacing the CPU	5-2
1. Removing the CPU	5-2

History of the changes is shown as the "Revision History" at the end of this data.

変更履歴は、"Revision History"として、本データ末に記載してあります。

Page

(to 5-2)

CHAPTER 1. SPECIFICATIONS

1-1. Specifications

		J		AM		EU		Α	.0
	VGN-A63	VGN-A73PS*	VGN-A73S*	VGN-A790	VGN-A417M	VGN-A417S	VGN-A497XP	VGN-A49CP	VGN-A49GP
CPU	PM/Do/750/1.86GHz	PM/Do/750/1.86GHz or PM/Do/740/1.73GHz or	PM/Do/770/2.13GHz or PM/Do/750/1.86GHz or PM/Do/740/1.73GHz or CelM/Do/370/1.50GHz	PM/Do/760/2GHz	PM/Do/750/1.86GHz	PM/Do/760/2GHz	PM/Do/760/2GHz	PM/Do/770/2.13GHz	PM/Do/770/2.13GHz
Graphic	Mobility Radeon X600	Mobility Radeon X600	Mobility Radeon X600	Mobility Radeon X600	Mobility Radeon X600	Mobility Radeon X600	Mobility Radeon X600	Mobility Radeon X600	Mobility Radeon X600
LCD	17.0"WXGA+"	17.0"WXGA+" or	17.0"WXGA+" or	17.0"WUXGA"	17.0"WXGA+"	17.0"WXGA+"	17.0"WUXGA"	17.0"WUXGA"	17.0"WUXGA"
	-	17.0"WUXGA"	17.0"WUXGA"	-	-	-	-	-	-
HDD	100GB	100GB or 80GB or 60GB or 40GB	100GB or 80GB or 60GB or 40GB	100GB	80GB	100GB	100GB	100GB	100GB
Memory	512MB/DDR2/400*1	1GB/DDR2/400*2 or 512MB/DDR2/400*2 or 256MB/DDR2/400*2	1GB/DDR2/400*2 or 512MB/DDR2/400*2 or 256MB/DDR2/400*2	512MB/DDR2/400*2	256MB/DDR2/400*2	512MB/DDR2/400*2	512MB/DDR2/400*2	512MB/DDR2/400*2	512MB/DDR2/400*2
QUANTITY(STANDARD/MAX)	512MB/2GB	2GB	2GB	1GB/2GB	512MB/2GB	1GB/2GB	1GB/2GB	1GB/2GB	1GB/2GB
OPT-DRIVE	DVD Multi Drive	DVD Multi Drive or Combo	DVD Multi Drive or Combo	DVD+/-RW -	DVD+/-RW -	DVD+/-RW -	DVD+/-RW -	DVD+/-RW -	DVD+/-RW -
AC ADAPTOR	AC19V7	AC19V7/AC19V10	AC19V7/AC19V10	AC19V7	AC19V10	AC19V7	AC19V10	AC19V7	AC19V7
BATTERY	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA	BP2EA
Wireless LAN	802.11b/g	802.11a/b/g	802.11a/b/g	802.11a/b/g	802.11b/g	802.11b/g	802.11b/g	802.11b/g	802.11b/g
Bluetooth	X	X	X	X	0	0	0	X	X
AV PR	0	O/X	O/X	0	X	0	X	X	X
Audio PR	X	X	X	X	X	X	X	0	0
W-Mouse	X	0	0	0	0	0	0	Х	Х
Memory Card Adapter	0	0	0	X	X	X	Х	0	0
Remote Controller	0	O/X	O/X	0	X	0	X	0	0
os	XP Home	XP Pro	XP Home	XP Home	XP Home	XP Home	XP Pro	XP Pro	XP Pro
				<u></u> [MA]	1 [MA]	1 [MA]	1 [MA]	<u>4</u> [MA]	<u>2</u> [MA]

 $[\]boldsymbol{\cdot}$ The trademarks of registered trademarks of above table, refer to page 2.


[•] The model that is accompanied by asterisk (*) is the CTO model.

[・]本表中の商標・登録商標については、2ページをご参照ください。

[・]機種名に(*)がつくものはCTOモデルです。


CHAPTER 2. BLOCK DIAGRAM

2-1. VGN-A Series



VGN-A63/A73PS/A73S (J) VGN-A790 (AM) VGN-A417M/A417S/A497XP (EU) VGN-A49CP/A49GP (AO)

2-2. Port Replicator (VGN-PRAV)




VGN-A63/A73PS/A73S (J) VGN-A790 (AM) VGN-A417M/A417S/A497XP (EU) VGN-A49CP/A49GP (AO)

CHAPTER 3.

FRAME HARNESS DIAGRAM

3-1. VGN-A Series




Confidential

VGN-A63/A73PS/A73S (J) VGN-A790 (AM) VGN-A417M/A417S/A497XP (EU) VGN-A49CP/A49GP (AO)

ANTENNA ANTENNA

3-2. Port Replicator (VGN-PRAV)



Confidential

CHAPTER 4.

EXPLODED VIEWS AND PARTS LIST

 The parts list is compiled by blocks of a palmrest and bottom etc. The sections of the parts list are different depending on the model. Please refer to list of contents shown in the below. 分解図と部品表は、パームレスト、ボトムなどのブロックご とに分かれています。機種によって部品表のセクションが 異なりますので、詳細は右下の一覧表を参照してください。

Section	Page
P-1. Palmrest	4-2
Main Board M-1. Main Board	4-4
B-1. Bottom	4-6
Optical Drive D-1. Optical Drive	4-8

<u>Section</u> <u>Pa</u>	ge
LCD	
L-1. LCD 17-inch WUXGA (Clear Black LCD)	
– Made by SH – 4-	-10
L-2. LCD 17-inch WXGA+ (Clear Black LCD)	
– Made by AU – 4-	-12
Accessories	
A-1. Accessories 4-	-14
A-2. Accessories 4-	-15
DIP Switch4-	-17

NOTE:

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- When two or more parts are shown, use the part described first as the main part.
- The parts marked "\$" are the High Value Modules (HVM).
- The parts marked "#" are the parts on which barcode label is attached.

For the barcode label, refer to CHAPTER 5.

- The parts marked " & " are the "Customer Replacable Parts (CRP)" that can be replaced by Field Customer Support. Especially the parts with the <&> mark require the special attention to use them. Here fore, check first whether the desired part is one of the targetted parts of the Customer Replaceable Parts(CRP), or the non-targetted parts by referring to the exploded view.
- Regarding the boards of this model, the discrete parts on the boards cannot be replaced. However, Some connectors can be replaced.
- The model that is accompanied by asterisk (*) is the CTO model.

The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque \triangle sont critiques pour la sécurité. Ne les remplacer que par une


pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

【使用上の注意】

- * 印の部品は常備在庫しておりません。
- 図面番号のない部品は供給しません。
- 併記部品の場合、上部記載部品をメイン部品として使用してください。
- 部品名称の前に\$印のついた部品は, High Value Module (HVM)です。
- 商品名称の前に#印のついた部品は、バーコードラベル貼付部品です。

- 交換可能な Customer Replacable Parts (CRP)です。 特に<&>印のついた部品は, 使い分けが必要な部品ですの で, 分解図で Customer Replacable Parts 対象部品か, 対象 外部品かを必ず御確認ください。
- 本モデルの基板については、基板上の各部品の修理は行う ことができません。ただし、一部のコネクタについては、 修理可能です。
- 機種名に(*) がつくのはCTO モデルです。

▲印の部品,または▲印付きの点線で囲まれた部品は,安全性を維持するために重要な部品です。従って 交換時は,必ず指定の部品を使用してください。



			Palmrest	Main Board	Bottom	Optical Drive	LCD	Accessory	Port Replicator
		A63	P-1	M-1	B-1	D-1	L-2	A-1	A-2 (J-PR)
		A73PS*	P-1	M-1	B-1	D-1	L-1, L-2	A-1	A-2 (J-PR)
	J	A73S*	P-1	M-1	B-1	D-1	L-1, L-2	A-1	A-2 (J-PR)
] [MΑ	A790	P-1	M-1	B-1	D-1	L-1	A-1	A-2 (U-PR)
[]		A417M	P-1	M-1	B-1	D-1	L-2	A-1	A-2 (E-PR)
] E	ΞU	A417S	P-1	M-1	B-1	D-1	L-2	A-1	A-2 (E-PR)
]		A497XP	P-1	M-1	B-1	D-1	L-1	A-1	A-2 (E-PR)
] [40	A49CP	P-1	M-1	B-1	D-1	L-1	A-1	A-2 (C-PR)
JĽ	-	A49GP	P-1	M-1	B-1	D-1	L-1	A-1	A-2 (C-PR)
									. CTO madel

* : CTO model

Confidential


VGN-A63/A73PS/A73S (J) VGN-A790 (AM) VGN-A417M/A417S/A497XP (EU) VGN-A49CP/A49GP (AO)

1\ [MA

4 [MA

2 [MA

P-1. Palmrest



Confidential

P-1. Palmrest


Ref. No.	Part No.	<u>Description</u>
1 2 3 4 6	A-1067-956-A A-1058-413-A A-1058-417-A A-1118-774-A X-4626-655-2	\$ SPEAKER (36MM) CABLE(20P), FLEXIBLE FLAT CABLE, KB LED COMPLETE PWB SWX-185 SE1P PALMREST ASSY
7	4-682-423-01	SE1 SPONGE BT
8	2-159-644-01	SE1P SHEET SPEAKER RING
9	4-682-556-01	SE1P SPEAKER BRACKET
10	X-4626-657-1	SE1P TP BKT ASSY
11	4-682-560-01	TOUCHPAD SHEET
12	2-103-688-01	SE1P TOUCHPAD GASKET
14	1-866-586-11	PWB(10P),FLEXIBLE PRINT
15	A-1058-428-A	PWB(10P),FLEXIBLE PRINT
16	1-796-911-12	WIDE TOUCH PAD
17	2-103-691-01	SE1P BATT MASK MYLAR A
18	2-103-689-01	SE1P KEYBOARD BRACKET MYLAR A
19	2-103-690-01	SE1P KEYBOARD BRACKET MYLAR B
20	2-103-692-01	SE1P PALMREST GASKET
21	2-159-642-01	SE1P LED PORON
22	2-159-643-01	SE1P KEYBOARD SUPPORT MYLAR
23	2-159-977-01	SE1P KEYBOARD SUPPORT MYLAR B
24	2-548-305-01	E1 MYLAR SPEAKER BKT
B2	4-672-836-21	SCREW, M2 SPECIAL HEAD,EG GRIP
B4	2-048-596-02	SCREW, +B EG GRIP
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD,EG GRIP

				J		ΑM		EU		Α	0
			A63	473PS*	A73S*	A790	A417M	A417S	A497XP	A49CP	A49GP
	Ref.No Part No.	Description		`				Ĺ	`	ĺ	
	5 1-478-650-11	& KEYBOARD UNIT (JP)	•	•	•						
[MA]	1-478-650-21	& KEYBOARD UNIT (US)		Ι	Ι	•				•	•
[MA]	1-478-640-11	& KEYBOARD UNIT (GB) & KEYBOARD UNIT (DE)		Ι	I		•	•	•		ı
	1-478-640-21	& KEYBOARD UNIT (DE)		Ι	<u> </u>		•	•	•		[
[MA]	1-478-640-31	& KEYBOARD UNIT (CH)		Т	<u> </u>	<u> </u>	•	•	<u> </u>	Ĺ	<u> </u>
[MA]	1-478-640-41	& KEYBOARD UNIT (FR) & KEYBOARD UNIT (IT)			1	<u> </u>	•	•	•	İ	l
[MA]	1-478-640-51	& KEYBOARD UNIT (IT)		Д	↓	ļ	•	•	•	Ĺ	ļ
[MA]	1-478-640-61	& KEYBOARD UNIT (ES)		Д	↓	ļ	•	•	•	Ĺ	ļ
[MA]		& KEYBOARD UNIT (SE)		Д	↓	ļ		L	•	Ĺ	ļ
[MA]	1-478-640-81	& KEYBOARD UNIT (PT)						ட	•		
[MA]	B39 4-681-432-11	SCREW (M2) (SPIN)		┖		•		ட	ш		
						MA₩	₩₩	₩Ą₩	MA∏V	₩₩	MAIR

This parts list contains two different types of parts.
The first type is the parts that are common to all models.
The other type is the parts that are different depending on each model.

- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*) がつくのはCTOモデルです。

M-1. Main Board



Confidential

M-1. Main Board

Ref. No.	Part No.		Description
301 304 305 306 307	A-1058-426-A A-1118-773-A 4-682-945-01 X-2022-962-2 4-682-478-01	\$ #	CABLE, RJ11 COMPLETE PWB MBX-128 SE1 2ND FAN MYLAR SE1 DC JACK HOLDER ASSY SE1 ODD INSULATOR
308 309 310 311 312	2-583-809-01 4-682-475-01 4-682-569-01 X-4626-661-1 1-756-038-11		RH MYLAR CARD BUS SE1 SHEET MINI-PCI SE1P CARD BOX BRACKET SE1P IO BRACKET ASSY BATTERY,NICKEL HYDROGEN
313 314 315 316 317	4-642-711-11 4-668-307-01 A-1058-414-A 1-819-065-11 A-1094-416-A		SHEET (BATTERY), ADHESIVE SHEET DIMM HARNESS,DC CONNECTOR,PC CARD RH FIN THERMAL MODULE
318 319 321 322 323	A-1098-807-A 2-103-694-01 1-417-539-11 4-682-465-02 2-103-444-01	\$ #	RH THERMAL MODULE SE1P VGA THERMAL PAD CARD,MODEM SE1 MYLAR DOOR DIMM SE1 EMI SPRING FIN
324 326 327 328 329	X-2022-963-1 4-683-063-01 2-176-527-01 2-103-452-01 2-103-693-01		SE1 EMI SPRING BATT-1 ASSY RJ11 BKT 2ND FAN MYLAR-1 CPU THERMAL PAD SE1P THERMAL MODULE GASKET
331 332	2-583-810-01 2-592-419-01		RH MYLAR BOARD MAIN SHIELD RH MYLAR CHIP
B1 B3 B4 B5 B6	4-672-836-01 4-672-834-41 2-048-596-02 4-672-836-11 4-656-703-01		SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, +B EG GRIP SCREW, +B EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2
B13 B14 B40	2-103-443-01 4-635-966-01 4-672-834-01		SE1 HEX2-5+7 SCREW(HEX) SCREW, +B EG GRIP

									J		ΑM		EU		AC	5
		Ref.No.	Part No.		Description			A63	A73PS*	A73S*	A790	A417M	A417S	A497XP	A49CP	A49GP
		302	6-707-261-01		IC RH80536GE	0462MSL7SL(PM-D	02.13)	T	•	•	П	\neg	\neg		•	•
Α	[MA]		6-707-260-01			0412MSL7SM(PM-I		1			•		•	•		
	. 1		6-707-259-01		IC RH80536GE)362MSL7S9(PM-D	O1.86)	•	•	•		•				
			6-707-258-01		IC RH80536GE	0302MSL7SA(PM-D	001.73)	1	•	•						
			6-707-268-01			0211MSL86J(CEL-I	OOM1.5)	1	•	•						
		303	6-707-350-01		IC HYS64T6402	0HDL-5-A(512MB) 21HDL-5-A(1GB)		•	•	•	•]	•	•	•	•
			6-707-504-01					I	•	•						
			6-707-352-01		IC HYS64T3200	0HDL-5-A(256MB)			•	•		•				
		320	1-761-864-61	#	WIRELESS LAN	I CARD		•								
			1-789-095-61	#	WIRELESS LAN	I CARD			•	•						
A	[MA]		1-789-095-51	#	WIRELESS LAN			l	l		•					
			1-761-864-71	#	WIRELESS LAN	I CARD						•	•	•	•	•
											[MA <u>₩</u>	[MA]	[MA]	[MA]	∰WY MY	[MA]


- 1) The DIP switch setting, refer to page 4-17 "DIP switch".
- 2) The CPU THERMAL PAD (Ref.328) cannot be re-used if it is removed once.

 When the FIN THERMAL MODULE (Ref.317) is removed, be sure to replace it with the new one.
- 3) When change the CPU (Ref.302), refer to "5-2 Replacing the CPU "in CHAPTER 5.
- 1) DIP スイッチの設定は、4-17 頁「DIP Switch」を参照してください。
- 2) CPU THERMAL PAD (Ref. 328) は、一度取り外したものを再利用することはできません。 FIN THERMAL MODULE (Ref. 317) をはずした場合には、必ず新しいものを交換してください。
- 3) CPU (Ref. 302) を交換する際は、CHAPTER 5、「5-2 CPU の交換」を参照してください。
- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
- The other type is the parts that are different depending on each model.

 This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に (*) がつくのはCTOモデルです。

Confidential

B-1. Bottom



●4) Ref.552 is a part that is only needed for Ref.534 A-1108-509-A.

4) Ref. 552は、A-1108-509-Aのみに必要な部品です。

B-1. Bottom

Ref. No.	Part No.			<u>Description</u>
7 501 502 504 505	4-682-423-01 A-1058-406-A A-1058-416-A A-1118-776-A A-1118-777-A	\$ #		SE1 SPONGE BT CABLE(26P), FLEXIBLE FLAT CABLE, ODD EJECT COMPLETE PWB CNX-290 COMPLETE PWB IFX-378
506 507 508 509 510	X-4626-658-4 4-682-454-01 4-682-455-01 4-682-460-01 4-682-457-01			SE1P BOTTOM ASSEY SE1 15S BATT BUTTON SE1 15S BATT BUTTON3 SE1 15S DOOR DOCK SE1 BATT LOCK
511 512 513 514 515	4-683-040-01 4-682-443-01 4-682-444-01 4-682-445-01 4-682-456-01		& &	SE1 DOCKING HOOK MYLAR SE1 FOOT FRONT SE1 FOOT FRONT CENTER SE1 FOOT REAR SE1 LATCH BATT
516 517 518 519 520	4-682-459-01 2-594-584-01 4-682-458-02 4-682-476-01 2-103-697-01			SE1 LATCH BATT SPRING RH EMI SPRING BATT SE1 LATCH LEVER SE1 SW BRACKET SE1P HDD MYLAR
521 522 523 524 525	2-103-698-01 4-682-447-01 X-4626-721-1 X-4626-653-1 X-4626-720-1		& & &	SE1P INSULATION AUDIO BD SE1 LCD LATCH DETECTOR SE1 DOOR I/O ASSY SE1 DIMM DOOR ASSY SE1 BATTERY DOOR ASSY
526 527 535 536 538	2-025-132-01 4-682-466-01 4-682-580-01 4-682-581-01 4-682-568-01		& &	LABEL BATTERY SE1 15S DOOR MODEM SE1P BRACKET HDD-L SE1P BRACKET HDD-R SE1P DISPLAY BASE
541 542 543 544 545	2-103-696-01 2-103-695-01 A-1118-775-A 1-865-674-11 4-682-462-01	\$		SE1P SHEET BLUETOOTH ANT SE1P BATT MASK MYLAR B COMPLETE PWB CNX-288 PWB(26P),FLEXIBLE PRINT SE1 15S MODEM R
547 550 551	2-067-843-01 2-159-787-01 2-583-811-01			EMI SPRING HDD SE1 SPONGE LENS RH MYLAR SATA HDD BOARD
B1 B2 B3 B5 B9	4-672-836-01 4-672-836-21 4-672-834-41 4-672-836-11 2-159-307-01		<&> <&> <&> <&>	SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, +B EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2.6+B EG GRIP
B11 B12 B18 B23 B24	4-672-839-01 4-672-840-01 4-672-834-21 3-254-029-11 4-672-834-71		<&> <&>	HEAD,M3 FLAT SCREW, M2 TAPPING,FLAT HEAD SCREW, +B EG GRIP SCREW SCREW,+B EG GRIP

															ı			ı	l	1	
														A63	A73PS*	A73S*	A790	A417M	A417S	A497XP	A49CP
L		Part No.			Desci										L	L	L	_	L	L	_
	503	A-1058-408-A			CABL						14//07	-\			•	•	•	•	•	•	<u> </u>
½ [MA] [528	4-682-449-01 4-682-449-11			 SE1 L								 		<u></u>	<u></u> -	ļ. <u></u> .	•	•	•	
-	500													•	•	•	•	_	Ļ	L	•
-	529	4-683-065-01			SE1P									_	•	•	•	•	•	•	Ļ
-	530 531	2-048-475-01	1		SE1P)		•	_		_	•	_		•
-	531	4-682-582-01			SE1P							\	_		•	•	•	•	•	÷	⊢
-	533	4-682-583-01 1-796-949-11			SE1P USB F						-ivious	se)	_		٠	÷	٠	÷	÷	÷	⊢
-	534		•								1001			_	٠	٠	٠	•	÷	÷	
	534	A-1105-612-A	<u>\$</u>	#	 HUU	1000	GB,H	0544	1010	1695/	100)		 	•			₽.		•		•
		A-1105-613-A A-1108-509-A	<u>.</u>	#	 HDD (HDD(i HDD(i		0,000	554 IU	10U)				 		•	ľ	ļ			ļ	ļ
		A-1105-509-A	Ď.	#	 HDD(VITI I	2000	CE 440	5) 1601				 			1	ļ			 -	ļ
KIMAI	539	1-805-554-21	φ	#	BLUE								_		•	•	Н	•	•	•	⊢
MAI	540	A-1058-407-A			CABL										⊢	\vdash	\vdash	÷	÷	÷	⊢
Z [IVIZ]	548	4-682-446-01			SE1 S					11 \				_				÷	-		-
-	552	2-583-812-01			AL FC				VV/VV	L)				•	-	-	•	•	•	•	•
L	302	2-303-012-01			ALIC	/IL J	חות	טטוו						_	_	_	MAI	[MA]	[MA]	[MA]	[MA]

- [MA] •1) Ref.539 and Ref.540 are parts for the models equipped with Bluetooth.
 - •2) Ref.503, 529, 531, 532, and 533 are parts for the models with a wireless mouse.
 - •3) Ref.530 is a part for the models without a wireless mouse.
 - •4) Ref.552 is a part that is only needed for Ref.534 A-1108-509-A.

- ↑ [MA] ●1) Ref. 539 とRef. 540 は、BULETOOTH 搭載モデル用の部品です。
 - ●2) Ref. 503, 529, 531, 532. 533 は、Wireless-Mouse 付モデル用の部品です。
 - ●3) Ref. 530 は、Wirelass-Mouse が付かないモデル用の部品です。
 - ●4) Ref. 552 は、Ref. 534 A-1108-509-Aのみに必要な部品です。
 - This parts list contains two different types of parts. The first type is the parts that are common to all models. The other type is the parts that are different depending on each model.
 - This model that is accompanied by asterisk (*) is the CTO model.
 - この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
 - 機種名に(*) がつくのはCTOモデルです。

Confidential

D-1. Optical Drive


How to Use Parts Differently.


This series of product uses the five diffrent types of the optical drive.

When replacing the optical drive, check the indication label of it, and use the same type of the optical drive.


Each optical drive has different types of the bezel.

For the how to identify the type of drive and the combination of the Bezel, refer to the details below.





<u></u> **⚠**[MA]




D-1. Optical Drive

Ref. No.	Part No.	<u>Description</u>
802	4-682-408-01	\$ SE1 CD BRACKET BACK
803	4-682-406-01	SE1 CD BRACKET L
804	4-682-407-01	SE1 CD BRACKET R
809	2-102-385-01	SE1 GASKET ODD
820	A-1118-778-A	COMPLETE PWB CNX-289
821	4-682-950-01	SE1 ODD BOARD MYLAR
B1	4-672-836-01	SCREW, M2 SPECIAL HEAD,EG GRIP
B5	4-672-836-11	SCREW, M2 SPECIAL HEAD
B17	4-671-538-01	SCREW(M2x4), SPECIAL HEAD

_													
						J		ΑM	Ш.	EU		A	2
					A63	A73PS*	A73S*	A790	A417M	A417S	A497XP	A49CP	A49GP
	Ref.N	lo Part No.		Description		1	l		ıl				
	810	1-797-066-11	\$ #	DVD+-RW(UJ-831BSX2-A)	•	•	•		П				\neg
<u> </u>	811	8-457-664-10	\$ #	DRIVE, DVD DW-D56A-V3		П		•	•	•	•	•	•
	814	1-797-053-21	\$ #	COMBO DRIVE(UJDA760)		•	•		П				\neg
	815	X-2024-227-1		SE2 PCC UJ830B DVD+-RW	•	•	•		П				
<u>∧</u> [MA]	816	X-2024-036-1		SE2 CD DW-D56A BEZEL ASSY				•	•	•	•	•	•
	819	X-2024-057-1		SE2 UJDA-760 BEZEL ASSY		•	•		П				
/A[ADD]	822	2-637-871-01		RH GASKET ODD		Т		•	•	•	•	•	•
	B19	4-645-177-01		SCREW(M1.7x3.5)	•	•	•		П				\neg
_								[MA]	[MA]	[MA]	[MA]	[MA]	[MA]

- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(*) がつくのはCTOモデルです。


L-1. LCD 17-inch WUXGA (Clear Black LCD)



Confidential


L-1. LCD 17-inch WUXGA (Clear Black LCD) – Made by SH –

Ref. No.	Part No.			<u>Description</u>
1001 1003 1004 1005 1006	4-682-380-01 A-8119-991-A X-4626-664-1 4-682-397-01 4-682-396-01		& &	SE1 COVER HINGE HARNESS, LCD FOR 17WUXGA SE1P BEZEL DISPLAY 17 ASM SE1 CUSHION LCD SIDE SE1 CUSHION LATCH
1007 1008 1009 1010 1011	4-682-395-01 4-682-398-01 4-682-388-01 4-682-390-02 2-024-790-01		& &	SE1 CUSHION LCD SE1 COVER SCREW SE1 HOOK PLATE LCD 2 HOOK LCD 15 SE1 GASKET AU LVDS DISPLAY
1013 1014 1015 1016 1017	A-1062-138-A 4-682-578-01 4-682-577-01 X-4626-663-1 4-682-576-01	\$ #		LCD_UNIT_(2CFL-17WUXGA)(S) SE1P HINGE LAMS SE1P HINGE RAMS SE1P HOUSING DISPLAY 17 2 ASM SE1P LCD BRACKET L
1018 1019 1020 1021 1022	4-682-575-01 1-478-629-22 2-159-645-01 2-190-716-01 2-190-717-01			SE1P LCD BRACKET R INVERTER UNIT(2CFL-17W) SE1P INVERTER ADHESIVE SE1P HOUSING AL L SE1P HOUSING AL R
1023 1057	2-190-718-01 2-583-807-01			SE1P HOUSING AL BTM RH FERRITE CORE BRH8X12X4
B1 B2 B5 B17 B22	4-672-836-01 4-672-836-21 4-672-836-11 4-671-538-01 2-108-227-01		<&>	SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW(M2x4),SPECIAL HEAD SPECIAL FLAT HEAD



- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に (*) がつくのはCTOモデルです。


L-2. LCD 17-inch WXGA+ (Clear Black LCD)



Confidential


L-2. LCD 17-inch WXGA+ (Clear Black LCD) – Made by AU –

Ref. No.	Part No.			Description
1001 1005 1006 1007 1008	4-682-380-01 4-682-397-01 4-682-396-01 4-682-395-01 4-682-398-01		& & & &	SE1 CUSHION LATCH
1009 1010 1011 1014 1015	4-682-388-01 4-682-390-02 2-024-790-01 4-682-578-01 4-682-577-01			SE1 HOOK PLATE LCD 2 HOOK LCD 15 SE1 GASKET AU LVDS DISPLAY SE1P HINGE LAMS SE1P HINGE RAMS
1016 1019 1020 1021 1022	X-4626-663-1 1-478-629-32 2-159-645-01 2-190-716-01 2-190-717-01			SE1P HOUSING DISPLAY 17 2 ASM INVERTER UNIT(2CFL-17W) SE1P INVERTER ADHESIVE SE1P HOUSING AL L SE1P HOUSING AL R
1023 1051 1052 1053 1054	2-190-718-01 X-2024-399-1 A-1074-808-A 2-176-382-01 2-176-383-01			SE1P HOUSING AL BTM SE2P BEZEL DISPLAY 17 AU HARNESS,LCD 17 WXGA SE2P LCD BRACKET L SE2P LCD BRACKET R
1055	A-1087-141-A	\$ #		"LCD_UNIT_(17WXGA)_(S)
1056 1057	2-342-994-01 2-583-807-01			SHIELD TAPE(AU17) RH FERRITE CORE BRH8X12X4
B1 B2 B5 B17 B22	4-672-836-01 4-672-836-21 4-672-836-11 4-671-538-01 2-108-227-01		<&>	SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW, M2 SPECIAL HEAD,EG GRIP SCREW(M2x4),SPECIAL HEAD SPECIAL FLAT HEAD



- This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に (*) がつくのはCTOモデルです。

A-1. Accessories



							J		ΑN		EU		Α	٩C
	Pef No.	Part No.			Description	A63	A73PS*	A73S*	A790	A417M	A417S	A497XP	A49CP	
ŀ	∆ 2001		•	2.	ADAPTOR, AC	+	•	•	\vdash					+
[MA]	2001	1-479-114-31	\$ \$		ADAPTOR, AC		ļ		ļ				ļ	┿
[IVI/	∆ 2011	1-478-037-34	\$ \$	8	ADAPTOR, AC	+	•	•	•			<u>.</u>	•	╬
[MA]	2011	1-478-037-41	\$	&	ADAPTOR, AC	 	ļ	<u>. </u>	ļ	 -	•			╬
ויייין	₾ 2002	A-1062-155-A	\$	- &	BATTERY 9130PA SNT (J) (S)		•	•			Ť		-	+
[MA]	∆ 2002	A-1062-133-A	\$		BATTERY 9130 (U)(S)		ļ		•					+
[MA]	∆ 2002	A-1062-142-A	\$	&	BATTERY 9130 (E)(S)		ļ	ļ	ļ		•	•	•	╬
[MA]	∆ 2002	1-555-074-32	Ψ	- &	CORD. POWER	+	\vdash	\vdash	\vdash	Ť	Ť	-	Ť	+
[MA]	∆ 2003	1-782-476-22		& &	CORD, POWER		ļ	ļ	ļ				•	╬
[MA]	∆ 2003	1-829-237-21			CORD. POWER		ļ	ļ	•	ļ	ļ			.∤.
[IVI/	∆ 2003	1-827-160-21			CORD. POWER	+	•	•	ļ	ļ			ļ	╅
[MA]	2004	1-823-935-51		- &	CORD, AC POWER(GB)	Ť	ř	ř	\vdash	•	•	•	\vdash	+
[,,,,,]	2005	1-829-239-11		- &	CORD, F TERMINAL WITH RF	•	•	•	•	Ť	Ť	-	\vdash	+
[MA]	2005	1-770-019-51		- &	ADAPTOR, CONVERSION PLUG 3P	Ť	ř	ř	ř					+
[MA]	2007	1-827-481-21		- &	POWER-SUPPLY CORD	+		\vdash			•	•		+
[MA]	2007	1-816-429-12		- &	PHONE PLUG (GB)	+	\vdash	\vdash	\vdash	•	•	•	\vdash	┧
[IVI/	2009	A-1126-412-A		- &	ASSY SPEAKER FW WE		•	•	•	Ť	•	•	•	+
ŀ	2010	A-1120-412-A			PORT REPLICATOR	1	:	•	•		•		•	+
ŀ	2010	1-478-615-11			MEMORY CARD ADAPTER	:	:	•	۳		•	H	•	+
ŀ	2022	1-796-824-32		- &	MOUSE (SLV)	Ť	•	•	•	•	•	•	Ť	+
ŀ	2022	1-478-688-11		- &	REMOTE COMMANDER (RM-VC10)		-	•	ř	Ť	Ť	•	\vdash	+
[MA]	2023	1-478-969-12			REMOTE COMMANDER (RM-VC10)	╇	•	•			•			+
[MA]	2024	1-479-090-11			REMOTE COMMANDER (KM-VC10E)	+					•		•	+
[MA]	2026	1-479-183-11		- &	REMOTE COMMANDER (RM-VC10U)	+	\vdash	\vdash	•	\vdash	\vdash		Ť	+
[IVI/	2027	A-1112-204-A		- &	OVERALL DA ASSY ,MAIN		•	•	ř	-			\vdash	+
ŀ	2021	2-629-499-01		- &	MANUAL (XP), INSTRUCTION	-	•	•						+
[MA]		2-633-046-11			WELCOME MAT, 3360(U) (C)	╇	•	•	•					+
[MA]		2-631-656-11		- &	TROUBLESHOOTING GUIDE	+	\vdash	\vdash	ř	\vdash	\vdash		\vdash	+
[MA]		2-631-656-31		- &	TROUBLESHOOTING GUIDE	+	\vdash	\vdash	\vdash	-	-		•	+
[MA]		2-629-974-11		- &		+	\vdash			•	•	•	ř	+
[MA]		2-629-974-61		&	HW SPECS, 3360(E) A GB, NL, SE, PT, BE, CZ HW SPECS, 3360(E) A NL, BE		ļ	·····	ļ	-		•	ļ	+
[MA]		2-629-974-01		&	HW SPECS, 3360(E) A DE, 4CH	+	ļ	ļ	 -	-	•	-	ļ	+
[MA]		2-629-974-21		& &	HW SPECS, 3360(E) A FR, 4CH, 1BE, BE	+	ļ	ļ	 -	-	-	-	ļ	+
[MA]		2-629-974-31		Q.	HW SPECS, 3360(E) A IT, 4CH	+	ļ	ļ	 -	-	-	-	ļ	+
[MA]		2-629-974-51			HW SPECS, 3360(E) A ES		ļ	ļ	ļ	•		•	ļ	⋅╁
[MA]		2-629-974-81			HW SPECS, 3360(E) A SE	+	ļ	ļ		ļ- <u>-</u> -	ļ- <u>-</u> -	-	 -	-
[MA]		2-629-974-81		& &	HW SPECS, 3360(E) A SE	+	ļ	ļ	ļ	ļ	ļ	-	 -	4
[MA]		2-629-974-91			HW SPECS, 3360(E) A PT	+	ļ	ļ	 -	·	·	-	ļ	+
[1417.7]		2-023-314-11		ά	11VV OF LOO, 3300(E) A F I	1			[MA]	[MA]	[MA[V]	[MA]	[MA]	, ,


③ [MA] [MA] ●1) Ref. 2005, 2009, 2010, 2011, 2023, 2024, 2025, 2026 は、Port Replicator 同梱機種のみについてきます。

●2) Ref. 2027 は、Pentium M 搭載機種のみに同梱されます。 (1-1. SPECIFICATIONをご参照ください)

- This model that is accompanied by asterisk (*) is the CTO model.
- 機種名に (*) がつくのはCTOモデルです。

Confidential

A-2. Accessories



Confidential

A-2. Accessories


Ref. No.	Part No.		Description	Ref. No.	Part No.			Description
2101	X-4626-667-1		SUB HOUSING UPPER BPR ASSY	2128	X-4626-669-1		•	SUB HOUSING BOTTOM BPR ASSY
2102	4-682-689-01		BPR MYLAR FOOT	2129	4-682-703-01		&	BPR RUBBET FOOT
2103	4-682-693-01		BPR CAP BOSS DOCK CONN	2130	2-048-440-01			APR MYLAR B2B CONNECTOR
2104	4-682-694-01		BPR BRACKET ARM TRAY	2132	X-4626-671-1			SUB FRAME BPR ASSY
2105	4-682-695-01		BPR HOOK FRONT	2133	4-682-710-01			BPR COVER RIGHT HOUSING UPPER
2106	4-682-697-01		BPR ARM SLIDE HOOK YOKO	2134	4-682-711-01			BPR COVER LEFT HOUSING UPPER
2107	4-682-698-01		BPR KNOB HOOK RELEASE	2135	A-1058-418-A			PWB (60P), FLEXIBLE PRINT A
2108	4-682-699-01		BPR KNOB HOOK RELEASE BOTTON	2136	A-1058-419-A			PWB (60P), FLEXIBLE PRINT B
2109	4-682-700-01		BPR PIN GND	2137	A-1058-420-A			CABLE, ETHER
2110	X-4626-672-1		SUB HOUSING TRAY BPR ASSY	2140	4-682-728-01			APR COVER BRACKET D-SUB-1
2111	4-682-721-01	&	BPR CUSHION REAR	2141	4-682-729-01			APR COVER BRACKET D-SUB-2
2112	4-682-720-01	&	BPR CUSHION FRONT	2142	2-048-439-01			BPR ENFORCE PLATE
2113	2-048-435-01	•	BPR MYLAR FPC	2143	2-103-312-01			MYLAR TOP SHIELD R
2114	A-1058-415-A		HARNESS. DC	2145	2-103-314-01			MYLAR 34x40
2115	A-1121-773-A	\$	COMPLETE PWB CNX-271	2147	2-103-316-01			GASKET 7x10x2
2116	4-682-690-01		BPR PLATE DOCK CONN UPPER	2148	2-103-317-01			MYLAR HOOK FRONT
2117	4-682-691-01		BPR PLATE DOCK CONN BOTTOM	2150	2-103-317-01			APR FOIL AL 6x24
2118	2-048-436-01		BPR MYLAR SHIELDING	2151	A-1123-316-A	\$		COMPLETE PWB IFX-312C
2119	X-2021-564-1		BPR ASSYSUB CAM SLIDE HOOK	2160	2-048-434-01	Ψ		BPR MYLAR BRACKET ARM TRAY
2120	2-048-437-01		BPR SPONGE CAM SLIDE HOOK	2161	2-103-313-01			BPR MYLAR TOP SHIELD L
2120	2-040-437-01		BER SPONGE CAN SLIDE HOOK	2101	2-103-313-01			BPR WITLAR TOP SHIELD L
2121	4-682-709-01		BPR ARM TRAY PIN	2162	2-148-338-01			BPR SPONGE USB 2 PORT
2122	4-682-712-01		BPR BRACKET DC					
2124	4-682-708-01		BPR LIGHT GUIDE LED	B31	4-635-966-01			SCREW (HEX)
2125	4-682-714-01		BPR SPRING TRAY R	B32	4-671-504-11		<&>	SCREW,TAPPING+P2.6
2126	4-682-715-01		BPR SPRING TRAY L	B33	3-906-376-01			SCREW(2.6x6)
				B34	4-639-112-31			SCREW M2X4
				B35	2-103-677-01			T3X8L, (I) B-NI
				B36	4-641-726-21		<&>	SCREW(M2),SPECIAL HEAD
				B37	4-671-538-01			SCREW(M2x4),SPECIAL HEAD
				B38	4-635-301-11			SCREW M3X4

					J-PR	U-PR	E-PR	C-PR
		Part No.	Description				ĺ	
A IMAI	2127	A-1123-317-A A-1123-324-A	\$ COMPLETE PWB CNX-250A2 COMPLETE PWB CNX-250C2		•	•	•	•
	2131	X-4626-673-1	SUB COVER IO AV1 APR1 ASSY		•	•	•	Г
Г	2144	2-103-240-01	MYLAR RCA 1PIN		•	•	•	Г
	2149	4-680-501-01	RF,CONN WASHER		•	•		Г
	2152	A-1123-314-A A-1123-319-A A-1123-321-A	\$ COMPLETE PWB ENX-29(J) COMPLETE PWB ENX-29(U) COMPLETE PWB ENX-34		•			Г
[MA] [A-1123-319-A	\$ COMPLETE PWB ENX-29(U)			•	ĺ	Ι'''
		A-1123-321-A	\$ COMPLETE PWB ENX-34				•	Ι'''
	2153	4-682-722-01	APR BRACKET TUNER		•	•		
Г	2154	4-680-482-01	RF CONN,NUT		•	•		Г
Г	2163	2-148-335-01	APR THERMAL PAD TUNER BIG		•	•		Г
	2164	2-148-336-01	APR THERMAL PAD TUNER SIDE		•	•		Г
Г	2165	X-2022-558-1	ASSY SUB HEATSINK TUNER		•	•	Г	Г
Г	2166	2-148-337-01	APR ADHESIVE HEATSINK TUNE	R MO	•	•		Г
	2167	X-2024-177-1	APR SUB FAN BRACKET ASSY				•	Г
<u> </u>	2168	2-318-497-01	APR ADHESIVE FAN BRACKET				•	Г
∑ [MA]	2169	A-1081-380-A	UDQFUMH07-AS DC FAN 105MM				•	Г
∑ [MA] ∑	2170	2-345-931-01	EPR MYLAR TUNER				•	Г
[MA] [2171	2-318-499-01	EPR BRACKET TUNER				•	Г
∑ [MA][2172	2-345-932-01	CPR SPACER DC					•
∑ [MA]	2173	2-345-933-01	CPR DUMMY BOARD					•
∑ [MA]	2174	X-2024-630-1	CPR COVER IO AV ASSY					•
	2175	2-345-934-01	CPR CAP S-VIDEO					•
MAj [MAj]	2176	2-345-935-01	CPR CAP VIDEO IN					•
MAI	2177	2-345-936-01	CPR CAP TUNER					•
⊼ [MA][2178	2-345-937-01	CPR MYLAR RCA					₩A ₹


- The destination is shown in the list of 4-1 for the Port Replicator. Please refer to list shown in the below.
- ポートリプリケーターの仕向けは、4-1の一覧表を参照ください。


DIP Switch

- The DIP switch setting is following table.
- ・DIPスイッチの設定は下の表をご参照ください。



[FOR CTO MODEL]





The DIP switch setting is different depending the types of LCD.

Set the DIP switch of the CTO model in accordance with the [FOR CTO MODEL].

DIP スイッチの設定は、LCD の種類によって異なります。

CTO モデルは、【FOR CTO MODEL】の表に従ってDIP スイッチを設定してください。


CHAPTER 5. **OTHER**

5-1. The Barcode Label


The hatched portion of the barcode is used as the repair data.

バーコードラベルの網掛け部は、修理データとして使用いたします。


[MBX-128 Board] (Side A)



[IFX-378 Board] (Side B)



[HDD] (Made by Hi) (Bottom)



Α : Parts No. В : Serial No.


C : Revision No. D : Product code

: Maker Barcode


: Global User ID (iLink)

G : Mac Address : Barcode


[MBX-128 Board] (Side B)




[LCD Unit] (Rear)




[Wireless LAN Card]



[Optical Drive] (Top)



[Port Replicator] (Rear)



Confidential

VGN-A63/A73PS/A73S (J) VGN-A790 (AM) VGN-A417M/A417S/A497XP (EU) VGN-A49CP/A49GP (AO)


[Modem Card]



5-2. Replacing the CPU


1. Removing the CPU

- ① Insert a flat-blade screwdriver into the notch as shown in the illustration and rotate it so that the protrusion comes to the lock release position.
- ② Pull the CPU gently upward to lift it out of the CPU socket.



2. Installing the CPU

- ① Align the triangle reference mark of the CPU with that of the CPU socket and insert all the pins of the CPU to the corresponding holes of the CPU socket.
- ② While pressing the two positions marked by O, insert the flat head (-) screwdriver into the specified position and rotate the screwdriver to the LOCK position.



Note:

Rotate a flat-blade screwdriver to the lock position securely. If not, the operation of the CPU may become unstable.

Confidential



VGN-A63/A73PS/A73S (J) VGN-A790 (AM) VGN-A417M/A417S/A497XP (EU) VGN-A49CP/A49GP (AO)

List of VGN-A Series (As of August, 2005)

Service Manual		Мос	del Name	
Part No.	J	АМ	EU	AO
9-876-367-XX	VGN-A50B VGN-A60B VGN-A60PS* VGN-A60S* VGN-A70P VGN-A70PS* VGN-A70S*	VGN-A130* VGN-A130P* VGN-A170* VGN-A170P* VGN-A190	VGN-A115B VGN-A115S VGN-A117S VGN-A195EP VGN-A195HP VGN-A197VP VGN-A197XP	VGN-A11C VGN-A13CP VGN-A15CP VGN-A15GP VGN-A15LP VGN-A17GP VGN-A17LP VGN-A17SP VGN-A17TP VGN-A19CP
9-876-374-XX		VGN-A140* VGN-A140B* VGN-A140P* VGN-A150 VGN-A160 VGN-A190F	VGN-A115M VGN-A115Z	VGN-A17CP VGN-A19GP VGN-A19LP VGN-A19SP VGN-A19TP
9-876-387-XX	VGN-A51PS1* VGN-A51PS2* VGN-A51S1* VGN-A51S2* VGN-A61B VGN-A71PS* VGN-A71S*	VGN-A230* VGN-A230B* VGN-A230P* VGN-A240* VGN-A240P* VGN-A250 VGN-A260 VGN-A270* VGN-A270P* VGN-A270P* VGN-A290 VGN-A290F	VGN-A215M VGN-A215Z VGN-A217M VGN-A217S VGN-A295HP VGN-A297XP	VGN-A21C VGN-A23CP VGN-A29CP VGN-A29GP VGN-A29LP VGN-A29SP VGN-A29TP
9-876-401-XX	VGN-A62B VGN-A72PB VGN-A72PS1* VGN-A72PS2* VGN-A72S1* VGN-A72S2*	VGN-A600* VGN-A600B* VGN-A600P* VGN-A690*	VN-A317M VN-A317S VN-A397XP	VGN-A39CP VGN-A39GP
9-876-419-XX	VGN-A63 VGN-A73PS* VGN-A73S*	VGN-A790	VGN-A417M VGN-A417S VGN-A497XP	VGN-A49CP VGN-A49GP

*: CTO Model

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

本マニュアルの一部、または全部について、無断で データの複製、複写、転載することを禁じます。

Revision History

Suffix	Ver.	Date		Contents	QM No.
-01	Ver. 1	2005.04.08	First Edition		
-02	Ver. 2	2005.04.21	<u> </u>	Front Page (Model Lineup), Page 1-1, Page 4-1, Page 4-3, Page 4-5 to 4-9, Page 4-11, Page 4-13 to 4-17, Back Cover	N2005_001AK
-03	Ver. 3	2005.05.13	2	Front Page (Model Lineup), Page 1-1, Page 4-1, Page 4-3, Page 4-5, Page 4-7, Page 4-9, Page 4-11, Page 4-14 to 4-17, Back Cover	N2005_004AK
-04	Ver. 4	2005.05.20	3	Front Page (Model Lineup), Page 1-1, Page 4-1 to 4-3, Page 4-5, Page 4-7, Page 4-9, Page 4-11, Page 4-14, Page 4-16 to 4-17, Back Cover	N2005_013AK
-05	Ver. 5	2005.07.07	4	Front Page (Model Lineup), Page 1-1, Page 4-1, Page 4-3, Page 4-5, Page 4-7, Page 4-9, Page 4-11, Page 4-14, Page 4-17, Back Cover	N2005_038AK
-06	Ver. 6	2005.08.11	5	Page 4-7 to 4-9	N2005_043CK
<rema< td=""><td>arke></td><td></td><td></td><td></td><td></td></rema<>	arke>				

<Remarks>

153

[Confidential]

VGN-A63/A73PS/A73S (J)

VGN-A790 (AM)

VGN-A417M/A417S/A497XP (EU)

VGN-A49CP/A49GP (AO)